





Operating Instructions

pico+15/l pico+25/l pico+35/l pico+100/l pico+15/U pico+25/U pico+35/U pico+100/U

Contact

Sensor Partners BV

James Wattlaan 15

5151 DP Drunen

The Netherlands

\$\&\ +31 (0)416 - 37 82 39

sensorpartners.com

Sensor Partners BVBA

Z.1 Researchpark 310

+32 (0)2 - 464 96 90 info@sensorpartners.com

sensorpartners.com

B-1731, Zellik Belgium

info@sensorpartners.com

pico+15/WK/I pico+25/WK/I pico+35/WK/I pico+100/WK/I pico+15/WK/U pico+25/WK/U pico+35/WK/U pico+100/WK/U

Ultrasonic sensor with one analogue output

Product Description

The pico+sensor offers a non-contact measurement of the distance to an object that has to be present within the sensor's detection zone. Depending on the set window limits, a distance-proportional analogue signal is output.

The window limits of the analogue output and its characteristic can be adjusted with the Teach-in procedure

Two LEDs indicate operation and the state of the analogue output.

Safety Notes

- Read the operating instructions prior to start-up.
- Connection, installation and adjustment works should be carried out by expert personnel only.
- No safety component in accordance with the EU Machine Directive

Proper use

pico+ultrasonic sensors are used for non-contact detection of objects.

Installation

- Mount the sensor at the installation site.
- Connect a connection cable to the M12 device plug.

Start-Up

- Connect the power supply.
- Carry out the sensor adjustment in accordance with the diagram.

2 • • 1 3 • 5 • 4		colour
1	+U _B	brown
3	-U _B	blue
4	-	black
2	IĮU	white
5	Com	grey

Fig. 1: Pin assignment with view onto sensor plug and colour coding of the microsonic connection cable

Factory Setting

- Rising analogue characteristic curve between the blind zone and the operating range
- Multifunctional input »Com« set to »Teach-in«

Synchronization

If the assembly distance falls below the values shown in Fig. 2, the internal synchronization should be used. For this purpose set the switched outputs of all sensors in accordance to the diagram »Sensor adjustment with Teach-in procedure« at first. Then set the multifunctional output »Com« to »synchronization« (see »Further settings«). Finally connect pin 5 of the sensors plug of all sensors.




Fig.2: Assembly distances, indicating syn-

Maintenance

microsonic sensors are maintenancefree. In case of excess caked-on dirt we recommend to clean the white sensor surface.

Notes

- The sensors of the pico+ family have a blind zone. Within this zone a distance measurement is not possible.
- The pico+ sensors are equipped with an internal temperature compensation. Due to the sensors self heating, the temperature compensation reaches its optimum working-point after approx. 20 minutes of operation.
- In the normal operating mode, an illuminated yellow LED signals the object is within the adjusted window limits
- If synchronization is activated the Teach-in is disabled (see »Further settings«).
- The sensor can be reset to its factory setting (see »Further settings«).
- Optionally all Teach-in and additional sensor parameter settings can be made using the LinkControl adapter (optional accessory) and the LinkControl software for windows®.

Sensor adjustment with Teach-in procedure Set window Set rising/falling output Switch Teach-in / synchronization Reset to factory setting marging Switch off power supply Switch off power supply Connect Com to -U_B Connect Com to -U_B Place object at position ① Switch on power supply Switch on power supply Keep Com connected to Connect Com for about Connect Com for about Keen Com connected to -Un for about 3 s until both LEDs flash flash simultaneously LEDs flash alternately both LEDs stop flashing Both LEDs: flash alternately Green LED: flashes Green LED: flashes Yellow LED: on: rising, off: falling Yellow LED: on: Teach-in Disconnect Com from -U_B Place object at position @ off: synchro before switching off characteristic nization nower sunnly To change output To change operation mode Connect Com for about characteristic connect 1 s to +U_B Com for about 1 s to +U_B Com for about 1 s to -U_B Wait for about 10 s Wait for about 10 s Normal operating mode Normal operating mode Set analogue output Further settings



2014/30/EU

Enclosure Type 1
For use only in industrial
machinery NFPA 79 applications.

